

Control Stations

BZC Series Explosion-proof Control Stations (Ex db IIB+H2)

Selection table of control station BZC (Ex db IIB+H2)

Enclosure type	Components arrangement	Cable entries and direction	Ordering code	Enclosure weight (kg)
I	     	2-M25 x 1.5 Bottom entry	40017.....	8.00
II	   	1-M32 x 1.5 or 2-M25 x 1.5 Bottom entry	40018.....	9.10
III	   	1-M32 x 1.5 or 3-M25 x 1.5 Bottom entry	40019.....	10.20
IV	  	1-M40 x 1.5 or 2-M32 x 1.5 or 4-M25 x 1.5 Bottom entry	40020.....	15.90
	  			
V	  	1-M40 x 1.5 or 4-M32 x 1.5 or 6-M25 x 1.5 Bottom entry	40021.....	27.50
VI	 	1-M40 x 1.5 or 4-M32 x 1.5 or 6-M25 x 1.5 Bottom entry	40022.....	40.00